

WiFi Adapter

TECHNICAL SPECIFICATION

P/N: 19003



The WiFi Adapter connects to your Control Interface to be able use your iPhone/iPad or the NeoControl app as the user interface. The WiFi Adapter can be used as an independent network or be joined to your existing home network.

Advanced installs may use the WiFi Adapter to use IP TCP Protocol to integrate into their system.

A Control Interface is required.

Specifications

Input Power, Connector	DC 5 ~ 36V @ 50mA, Phoenix Connector or Barrel Jack
Operating Temp.	-20°C ~ 85°C
Operating Humidity	5 ~ 95% RH
Wireless Standard	802.11 b/g/n
Wireless Network	AP, STA, AP+STA
Output Interface, Connector	RS232, DB9 Cable
Size of Case w/ Antenna	124mm x 89mm x 25mm

StellarSky
SYSTEMS

www.StellarSkySystems.com