

Control Interface

TECHNICAL SPECIFICATION

P/N: 19002



Unlock the full potential of your StellarSky panels with the Control Interface.

Simply connect the CAT5/6 lead wire from your StellarSky panel and the Control Interface will transfer power as well as pass along communication from one of the control options.

Connect the WiFi Adapter with the DB9 port to control with NeoControl or the StellarSky app.
Connect any third party automation system with the DB9 port or the RS232 phoenix connector.

Can connect with another Control Interface to expand your system.

Specifications

Input Power, Connector	DC 12V up to 6A, Phoenix Connector
Operating Temp.	-20°C ~ 85°C
Operating Humidity	5 ~ 95% RH
Input Interface, Connector	RS232, DB9 Cable or RS232, Phoenix Connector
Input Interface, Connector	StellarSkySystem, RJ45
Output Interface, Connector	StellarSkySystem, RJ45, 12VDC @ 6A
Size of Case	65mm x 76mm x 34mm

StellarSky
SYSTEMS

www.StellarSkySystems.com