Ambience

WIRING DIAGRAM

StellarSky
SYSTEMS

CONNECT
TO NEXT AMBIENCE
OR NIGHT SKY PANELS

CONNECT
FROM CONTROL INTERFACE
OR AMBIENCE

THIRD PARTY
HOME AUTOMATION

RS232 PORT
9600 8n1

May use StellarSkySystem connections
to daisy chain Ambience controllers after
third party connection to first controller

TX   RX   GND

StellarSky
SYSTEMS

Ambience
PART# 21001

−   −   +   +

+   +   R   G   B   W

TO
POWER SUPPLY

TO
RGBW LED STRIP