Stellar Sky

NIGHTSKY STAR ENGINE

Our NightSky star engines are compact yet powerful. With 8 low voltage LEDs our star engines provide a realistic twinkle and slow movement like the real night sky.

We use our NightSky star engines in our star panels and star kits.

Use the standalone mode, StellarSky app, or integrated with a third party system.

Standalone Modes

☆ NightSky & NightSky Relaxed

Indulge in the many wellness benefits stargazing offers whenever you please. With realistic twinkle and slow movement at you'll fall in love with your view.

Enjoy at full brightness or dimmed by fifty percent.

- Solid Stars Without Movement Experience stars in a solid state at 100%, 50%, and 25% brightness.
- Desert Sky
 Imagine looking up at a desert night sky through heavy haze and winds.
 Realistic movement will transport you to your own desert oasis.
- ☆ Stormy Sky.

Watch the night sky through a quick moving storm from the comfort and safety of your own home.

☆ Disco Club

A combination of pulsing and bouncing stars is the perfect addition to your dance par-tayy!

- Enhancements
 - Our Stellar Technology gives us the power to use one star engine as a star field, falling star, constellation, or meteor shower!

 Set enhancements to trigger every minute, 5 minutes, or 10 minutes.
- Change the Density of the Stars

 Reduce or increase the density of your star field by fifty percent.

Stellar Sky

NIGHTSKY STAR ENGINE

Unlock control with our Control Interface

Be the captain of the stars with the added ability to adjust the brightness, and speed of movement for your stars!

- 🖒 Desert Sky 🌣 Stormy Sky 🌣 Disco Club
 - ☆ NightSky & NightSky Relaxed.
 - Solid Stars Without Movement

☆ Enhancements

Wish upon a falling star whenever your heart desires. With added control you can adjust the brightness, speed, and timing of our falling stars and meteor showers!

Create a stellar experience with constellation controllability.

Control two constellations individually or together.

Adjust the brightness, and twinkle speed,

- ☆ Change the Density of the Stars
 Reduce or increase the density of your star field from 1% to 100%.
- ☆ Sleep Timer
 Set a timer to power down your star field or entire StellarSky System. Sleep
 - timer to power down your star field or entire StellarSky System. Sleep
- ☆ Toggle Commands
- ☆ Discrete Power Commands
- ☆ Factory Reset





NIGHTSKY STAR ENGINE

Our NightSky star engines are compact yet powerful. With 8 low voltage LEDs our star engines provide a realistic twinkle and slow movement like the real night sky. We use our NightSky star engines in our star panels and star kits. Use the standalone mode, StellarSky app, or integrated with a third party system.

Standalone Modes

- ☆ NightSky & NightSky Relaxed
- Indulge in the many wellness benefits stargazing offers whenever you please. With realistic twinkle and slow movement at you'll fall in love with your view.

 Enjoy at full brightness or dimmed by fifty percent.
- ☆ Solid Stars Without Movement Experience stars in a solid state at 100%, 50%, and 25% brightness.
- ☆ Desert Sky
- Imagine looking up at a desert night sky through heavy haze and winds. Realistic movement will transport you to your own desert oasis.
- ☆ Stormy Sky
 - Watch the night sky through a quick moving storm from the comfort and safety of your own home.
- ☆ Enhancements
 - Our Stellar Technology gives us the power to use one star engine as a star field, falling star, constellation, or meteor shower!

 Set enhancements to trigger every minute, 5 minutes, or 10 minutes.
- ☆ Change the Density of the Stars Reduce or increase the density of your star field by fifty percent.



NIGHTSKY STAR ENGINE

Unlock control with our Control Interface

Be the captain of the stars with the added ability to adjust the brightness, and speed of movement for your stars!

- ☆ Desert Sky ☆ Stormy Sky ☆ Disco Club
 - ☆ NightSky & NightSky Relaxed
 - ☆ Solid Stars Without Movement

☆ Enhancements

Wish upon a falling star whenever your heart desires. With added control you can adjust the brightness, speed, and timing of our falling stars and meteor showers!

Create a stellar experience with constellation controllability.

Control two constellations individually or together.

Adjust the brightness, and twinkle speed,

- ☆ Change the Density of the Stars Reduce or increase the density of your star field from 1% to 100%.
- Sleep Timer

 Set a timer to power down your star field or entire StellarSky System. Sleep

 timer range is from 1 minute to 4 hours and 15 minutes.
- ☆ Toggle Commands
- ☆ Discrete Power Commands
- ☆ Factory Reset

